
MIN drill dimension between **Spout** and **Handle** 把手與出水口最小安裝距離 ø35.0(1.38")



INSTALLATION INSTRUCTION for Two-Handles Bathtub Faucet

浴缸龍頭組安裝說明

- 1. Drill 3 holes on appropriate position as shown in figure 1. 如Fig. 1 所示在適當的位置鑽3個孔.
- 2. Disassemble **Handles** and **Valve-Nuts** from **Valves** before installing as shown in figure 2. 如Fig. 2 所示安裝前將把手與閥體螺帽從把手閥體拆下.
- 3. a. Insert the **Spout** through the Ø35mm(1.38") hole , then secure **Spout** by tightening Connetor and Lock-Nut with Washer, then fasten Hose Connector (make sure O-ring seals have to be installed into grooves before join together with **Hose Connector**) as shown in figure 3.


如 Fig. a 所示先將接頭塞入出水口底部的連接管,如 Fig. 3 所示將出水口穿過 Ø35mm(1.38")的孔, 然後鎖緊固定螺帽和墊片來固定出水口. 再接上軟管連接器. (裝上軟管連接器之前, 請先確認 O型橡皮環已裝在溝槽內)


b. Insert the Valve Bodys from below through the Ø35mm(1.38") holes and fasten the Valve-Nuts, then secure the Valve Bodys by tightening the Lock-Nuts with Washer . Before fasten **Handles**, ensure that handle's are properly aligned when **Valves** are in closed position. Then, tighten Handles and insert the Caps.

如Fig. 3 所示將把手閥體從下方穿過ø35mm(1.38")的孔並且鎖入閥體螺帽, 然後鎖緊固定螺帽 和墊片來固定把手閥體. 完全固定前,當閥體關閉時,請先確認各把手朝向同一方向. 固定把手後, 再蓋上裝飾蓋.

4. a. Connect Valve Bodys to Spout Connector and water supplies with Flexible **Hoses** as shown in figure 4.

如Fig. 4 所示用不銹鋼軟管連接把手含閥體到軟管連接器以及供水口.





FIXING CONTENTS

組配件內容

